

Please install the drivers and applications as follow:

## Drivers

### **Intel Chipset Software Installation Utility**

1. Execute \Chipset.EXE.
2. Follow the installation wizard that appears.
3. At the License Agreement dialog, read the agreement. Click I Agree to continue with the installation.

NOTE: Several setup boxes may briefly appear during the installation. Follow the installation wizard that appears.

4. When the installation finishes, please restart the computer if needed.

### **ATI Video driver**

Please double check the H/W SPEC if the unit is built-in Intel Graphics Device please install this driver if the unit is built-in ATI Graphics Device please skip this step.

1. Execute \Drivers\Graphics-ATI.EXE file.
2. Follow the installation wizard that appears.
3. At the License Agreement dialog, read the agreement. Click I Agree to continue with the installation.

NOTE: Several setup boxes may briefly appear during the installation. Follow the installation wizard that appears.

4. When the installation finishes, please restart the computer if needed.

### **Intel Video driver**

Please double check the H/W SPEC if the unit is built-in ATI Graphics Device please install this driver if the unit is built-in Intel Graphics Device please skip this step.

1. Execute \Drivers\Graphics-Intel.EXE file.
2. Follow the installation wizard that appears.
3. At the License Agreement dialog, read the agreement. Click I Agree to continue with the installation.

NOTE: Several setup boxes may briefly appear during the installation. Follow the installation wizard that appears.

4. When the installation finishes, please restart the computer if needed.

### **Hotfix - kb835221.exe**

1. Execute \kb835221.exe.
2. Follow the installation wizard that appears.
3. At the License Agreement dialog, read the agreement. Click I Agree to continue with the installation.

NOTE: Several setup boxes may briefly appear during the installation. Follow the installation wizard that appears.

4. When the installation finishes, please restart the computer if needed.

### **Realtek High Definition Audio CODEC**

1. Execute \Audio.EXE.
2. Follow the installation wizard that appears.
3. At the License Agreement dialog, read the agreement. Click I Agree to continue with the installation.

NOTE: Several setup boxes may briefly appear during the installation. Follow the

installation wizard that appears.

4. When the installation finishes, please restart the computer if needed.

#### **HDAUDIO SoftV92 Data Fax Modem with SmartCP**

1. Execute **\Modem.EXE**.

2. Follow the installation wizard that appears.

3. At the License Agreement dialog, read the agreement. Click I Agree to continue with the installation.

NOTE: Several setup boxes may briefly appear during the installation. Follow the installation wizard that appears.

4. When the installation finishes, please restart the computer if needed.

#### **Touch Chip Fingerprint Coprocessor**

1. Execute **\Fingerprint.EXE**.

2. Follow the installation wizard that appears.

3. At the License Agreement dialog, read the agreement. Click I Agree to continue with the installation.

NOTE: Several setup boxes may briefly appear during the installation. Follow the installation wizard that appears.

4. When the installation finishes, please restart the computer if needed.

#### **Texas Instruments PCIXX12 Integrated FlashMedia Controller**

1. Execute **\Memory\_Sticker.EXE**.

2. Follow the installation wizard that appears.

3. At the License Agreement dialog, read the agreement. Click I Agree to continue with the installation.

NOTE: Several setup boxes may briefly appear during the installation. Follow the installation wizard that appears.

4. When the installation finishes, please restart the computer if needed.

#### **Memory Sticker Icon**

1. Execute **\MSIcon.EXE**.

2. Follow the installation wizard that appears.

3. At the License Agreement dialog, read the agreement. Click I Agree to continue with the installation.

NOTE: Several setup boxes may briefly appear during the installation. Follow the installation wizard that appears.

4. When the installation finishes, please restart the computer if needed.

#### **Synaptics PS/2 Port Pointing Device**

1. Execute **\Pointing.EXE**.

2. Follow the installation wizard that appears.

3. At the License Agreement dialog, read the agreement. Click I Agree to continue with the installation.

NOTE: Several setup boxes may briefly appear during the installation. Follow the installation wizard that appears.

4. When the installation finishes, please restart the computer if needed.

### **Realtek rtl8139/810x Family Fast Ethernet NIC**

1. Execute **\LAN.EXE**.
2. Follow the installation wizard that appears.
3. At the License Agreement dialog, read the agreement. Click I Agree to continue with the installation.

NOTE: Several setup boxes may briefly appear during the installation. Follow the installation wizard that appears.

4. When the installation finishes, please restart the computer if needed.

### **Intel ProSet/Wireless**

1. Execute **\Wireless-Intel.EXE**.
2. Follow the installation wizard that appears.
3. At the License Agreement dialog, read the agreement. Click I Agree to continue with the installation.

NOTE: Several setup boxes may briefly appear during the installation. Follow the installation wizard that appears.

4. When the installation finishes, please restart the computer if needed.

### **Atheros AR5006X Wireless Network Adapter**

1. Execute **\Wireless-Atheros.EXE**.
2. Follow the installation wizard that appears.
3. At the License Agreement dialog, read the agreement. Click I Agree to continue with the installation.

NOTE: Several setup boxes may briefly appear during the installation. Follow the installation wizard that appears.

4. When the installation finishes, please restart the computer if needed.

### **Toshiba Bluetooth Stack**

1. Execute **\Bluetooth.EXE**.
2. Follow the installation wizard that appears.
3. At the License Agreement dialog, read the agreement. Click I Agree to continue with the installation.

NOTE: Several setup boxes may briefly appear during the installation. Follow the installation wizard that appears.

4. When the installation finishes, please restart the computer if needed.

### **Camera Driver**

1. Execute **\Camera.EXE**.
2. Follow the installation wizard that appears.
3. At the License Agreement dialog, read the agreement. Click I Agree to continue with the installation.

NOTE: Several setup boxes may briefly appear during the installation. Follow the installation wizard that appears.

4. When the installation finishes, please restart the computer if needed.

### **Sony NC**

1. Execute **\Sony\_NC.EXE**.

2. Follow the installation wizard that appears.
3. At the License Agreement dialog, read the agreement. Click I Agree to continue with the installation.

NOTE: Several setup boxes may briefly appear during the installation. Follow the installation wizard that appears.

4. When the installation finishes, please restart the computer if needed.

### **Sony Image Filter**

1. Execute \ **SonyImgF.EXE**.
2. Follow the installation wizard that appears.
3. At the License Agreement dialog, read the agreement. Click I Agree to continue with the installation.

NOTE: Several setup boxes may briefly appear during the installation. Follow the installation wizard that appears.

4. When the installation finishes, please restart the computer if needed.

Applications

### **Sony Shared Library**

1. Execute \ **Sony\_Shared\_Library.EXE**.
2. Follow the installation wizard that appears.
3. At the License Agreement dialog, read the agreement. Click I Agree to continue with the installation.

NOTE: Several setup boxes may briefly appear during the installation. Follow the installation wizard that appears.

4. When the installation finishes, please restart the computer if needed.

### **Sony Utilities DLL**

1. Execute \ **Sony\_Utilities\_DLL.EXE**.
2. Follow the installation wizard that appears.
3. At the License Agreement dialog, read the agreement. Click I Agree to continue with the installation.

NOTE: Several setup boxes may briefly appear during the installation. Follow the installation wizard that appears.

4. When the installation finishes, please restart the computer if needed.

### **VAIO Event Service**

1. Execute \ **VAIO\_Event\_Service.EXE**.
2. Follow the installation wizard that appears.
3. At the License Agreement dialog, read the agreement. Click I Agree to continue with the installation.

NOTE: Several setup boxes may briefly appear during the installation. Follow the installation wizard that appears.

4. When the installation finishes, please restart the computer if needed.

### **VAIO Event Service Hotfix**

1. Execute \ **vaio\_event\_service\_hotfix.EXE**.
2. Follow the installation wizard that appears.
3. At the License Agreement dialog, read the agreement. Click I Agree to continue with the installation.

NOTE: Several setup boxes may briefly appear during the installation. Follow the installation wizard that appears.

4. When the installation finishes, please restart the computer if needed.

### **Setting Utility Series**

1. Execute \ **Setting\_Utility\_Series.EXE**.
2. Follow the installation wizard that appears.
3. At the License Agreement dialog, read the agreement. Click I Agree to continue with the installation.

NOTE: Several setup boxes may briefly appear during the installation. Follow the installation wizard that appears.

4. When the installation finishes, please restart the computer if needed.

### **VAIO Control Center**

1. Execute \ **VAIO\_Control\_Center.EXE**.
2. Follow the installation wizard that appears.
3. At the License Agreement dialog, read the agreement. Click I Agree to continue with the installation.

NOTE: Several setup boxes may briefly appear during the installation. Follow the installation wizard that appears.

4. When the installation finishes, please restart the computer if needed.

### **VAIO Power Management**

1. Execute \ **VAIO\_Power\_Management.EXE**.
2. Follow the installation wizard that appears.
3. At the License Agreement dialog, read the agreement. Click I Agree to continue with the installation.

NOTE: Several setup boxes may briefly appear during the installation. Follow the installation wizard that appears.

4. When the installation finishes, please restart the computer if needed.

### **Wireless Switch Setting Utility**

1. Execute \ **Wireless\_Switch\_Setting\_Utility.EXE**.
2. Follow the installation wizard that appears.
3. At the License Agreement dialog, read the agreement. Click I Agree to continue with the installation.

NOTE: Several setup boxes may briefly appear during the installation. Follow the installation wizard that appears.

4. When the installation finishes, please restart the computer if needed.

### **VAIO Camera Capture Utility**

1. Execute \ **VAIO\_Camera\_Capture\_Utility.EXE**.
2. Follow the installation wizard that appears.

3. At the License Agreement dialog, read the agreement. Click I Agree to continue with the installation.

NOTE: Several setup boxes may briefly appear during the installation. Follow the installation wizard that appears.

4. When the installation finishes, please restart the computer if needed.

### **VAIO Camera Utility**

1. Execute \ **VAIO\_Camera\_Utility.EXE**.

2. Follow the installation wizard that appears.

3. At the License Agreement dialog, read the agreement. Click I Agree to continue with the installation.

NOTE: Several setup boxes may briefly appear during the installation. Follow the installation wizard that appears.

4. When the installation finishes, please restart the computer if needed.

### **Suite QL**

1. Execute \ **Suite\_QL.exe**.

2. Follow the installation wizard that appears.

3. At the License Agreement dialog, read the agreement. Click I Agree to continue with the installation.

NOTE: Several setup boxes may briefly appear during the installation. Follow the installation wizard that appears.

4. When the installation finishes, please restart the computer if needed.